E·XFL



Welcome to E-XFL.COM

Understanding <u>Embedded - Microcontroller,</u> <u>Microprocessor, FPGA Modules</u>

Embedded - Microcontroller, Microprocessor, and FPGA Modules are fundamental components in modern electronic systems, offering a wide range of functionalities and capabilities. Microcontrollers are compact integrated circuits designed to execute specific control tasks within an embedded system. They typically include a processor, memory, and input/output peripherals on a single chip. Microprocessors, on the other hand, are more powerful processing units used in complex computing tasks, often requiring external memory and peripherals. FPGAs (Field Programmable Gate Arrays) are highly flexible devices that can be configured by the user to perform specific logic functions, making them invaluable in applications requiring customization and adaptability.

Applications of Embedded - Microcontroller,

Details	
Product Status	Obsolete
Module/Board Type	MCU, USB Core
Core Processor	SX48
Co-Processor	FT245RL
Speed	50MHz
Flash Size	4КВ
RAM Size	262B
Connector Type	USB - B, Pin Header
Size / Dimension	2.24" x 0.9" (56.9mm x 22.9mm)
Operating Temperature	-
Purchase URL	https://www.e-xfl.com/product-detail/dlp-design/dlp-245sy-g

Email: info@E-XFL.COM

Address: Room A, 16/F, Full Win Commercial Centre, 573 Nathan Road, Mongkok, Hong Kong





USB / Microcontroller Module



The DLP-245SY-G combines the 4th generation FT245RL USB interface IC from FTDI with a Parallax SX48 microcontroller to form a rapid development tool. The SX48 microcontroller is preprogrammed with basic functionality for accessing the port pins and can be reprogrammed with user developed firmware via a 5-pin header (4 pins used for compatibility with device programmers and debuggers from other manufacturers).

DLP-245SY-G FEATURES

- Send/receive data over USB to a host computer at up to 7 megabits per second
- 20 digital I/O lines plus the 8-bit data bus available for interfacing to user electronics
- Ubicom SX48 processor with 4K FLASH ROM, 262 bytes RAM, and a 2K (256x8) EEPROM
- Microcontroller Supervisor -- microcontroller held in reset until supply voltage reaches stable operating level
- "Token I/O" code preprogrammed into the SX48's ROM for basic port pin input/output capability including access to the EEPROM, and external digital temperature sensors. ROM can be easily erased and reprogrammed using a device programmer (purchased separately)
- No in-depth knowledge of USB is required as all USB protocol is handled automatically by the on-board FT245RL and its support circuitry
- Royalty-free device drivers eliminate the need for USB driver development
- Required 5V supply can be taken directly from the USB port or supplied by user electronics

- USB 1.1 and USB 2.0 compatible
- USB VID, PID, serial number, and product description strings stored in EEPROM area of USB IC
- Virtual com port (VCP) drivers for:
 - Windows 98 and Windows 98 SE
 - Windows 2000/ME/XP
 - Windows CE
 - MAC OS-8 and OS-9
 - MAC OS-X
 - Linux 2.40 and greater
- D2XX (USB direct drivers + DLL S/W interface)
 - Windows 98 and Windows 98 SE
 - Windows 2000/ME/XP/x64

APPLICATION AREAS

- Prototype development
- USB ISDN and ADSL modems
- USB interface for digital cameras
- USB interface for MP3 players
- High-speed USB instrumentation
- USB smart-card readers
- Set top box (STB) PC-USB interface
- USB hardware modems
- USB wireless modems
- USB bar code readers

GENERAL DESCRIPTION

The DLP-245SY-G provides a cost-effective, microcontroller-based method of interfacing an electronic peripheral to a host computer via USB.

To send data from the peripheral to the host computer, the microcontroller simply writes the byte-wide data into the FT245RL when TXE# is low. If the FT245RL's transmit buffer fills up or is busy storing the previously written byte, it will take its TXE# high in order to stop further data from being written until some of the FIFO data has been transferred over USB to the host.

When the host sends data to the peripheral over USB, the FT245RL will take RXF# low to let the microcontroller know that at least one byte of data is available. The microcontroller then reads the data until RXF# goes high indicating that no more data is available to read.

By using FTDI's virtual COM port drivers, the peripheral looks like a standard COM port to the application software. Commands to set the baud rate are ignored--the FT245RL always transfers data at its fastest rate (up to 3 megabits per second using VCP drivers) regardless of the application's baud-rate setting. The latest versions of the drivers are available for download from DLP Design's website at <u>http://www.dlpdesign.com</u>.

DRIVER SOFTWARE

FTDI's VCP (virtual COM port) driver-executable files are provided royalty free on the condition that they are used only with designs incorporating an FTDI device (i.e. the FT245RL and DLP-245SY-G). The latest version of the drivers can be downloaded from dlpdesign.com or ftdichip.com. Once loaded, the VCP drivers allow your application software running on the host PC to communicate with the DLP-245SY-G as though it were connected to a COM (RS-232) port.

In addition to VCP drivers, FTDI's D2XX direct drivers for Windows offer an alternative solution to the VCP drivers that allow application software to interface with the DLP-245SY-G using a DLL instead of a virtual com port. The architecture of the D2XX drivers consists of a Windows WDM driver that communicates with the FT245RL device via the Windows USB stack and a DLL that interfaces the application software (written in VC++, C++ Builder, Delphi, VB, etc.) to the WDM driver. An INF installation file, uninstaller program, and D2XX Programmer's Guide complete the package.

The D2XX direct drivers add support for simultaneous access and control of multiple FT245RL devices. The extended open function (FT_OpenEx) allows the device to be opened either by its product description or serial number, both of which can be programmed to be unique. The list devices function (FT-ListDevices) allows the application software to determine which devices are currently available for use, again by product description or by serial number.

Several new features have been recently added to the D2XX drivers. Functions are provided to program the EEPROM (FT_EE_Program) and read the EEPROM (FT_EE_Read). Unused space in the EEPROM is called the user area (EEUA), and functions are provided to access the EEUA.

3

FT_EE_UASize gets its size, FT_EE_UAWrite writes data into it, and FT_EE_UARead is used to read its contents.

Download FTDI Application Notes AN232-03, AN232-05, AN232-06, and AN232-07 for detailed instructions on how to install and remove the drivers.

EEPROM WRITE UTILITY

The DLP-245SY-G has the option to accept manufacturer-specific information that is written into the EEPROM area of the FT245RL. Parameters that can be programmed include the VID and the PID identifiers, the manufacturer's product string, and a serial number.

MPROG is the latest EEPROM serializer utility from FTDI for the FT245RL device. MPROG uses the new D2XX drivers and will work on Windows 98, Windows ME, and Windows 2000/XP platforms. You must install the latest release of the D2XX drivers in order to run this application.

QUICK START GUIDE

This guide requires the use of a Windows 98/2000/XP PC that is equipped with a USB port.

- Download the DLL version of the device drivers from either <u>dlpdesign.com</u> or <u>ftdichip.com</u>. Unzip the drivers onto a blank floppy disk or into a folder on the hard drive.
- The board can be configured to receive its operating power from the USB port or from user electronics. Pins 18, 19, and 20 allow for this configuration. (Refer to the Pinout Description in the next section for a detailed description of the DLP-245SY-G electrical interface.)

<u>Note</u>: The board will not operate until a power source has been selected as mentioned in Step 2.

3. Connect the DLP-245SY-G board to the PC via a standard A-B, 6-foot USB cable. This action initiates the loading of the USB drivers. When prompted, select the folder where the DLL version of the device drivers was stored in Step 1. Windows will then complete the installation of the device drivers for the DLP-245SY-G. The next time the DLP-245SY-G is

attached, the host PC will immediately load the correct drivers without any prompting. Reboot the PC if prompted to do so.

The DLP-245SY-G is shipped with default VID, PID, etc. values programmed into the EEPROM. You only need to run MPROG if you want to change the default values.

At this point, the DLP-245SY-G is ready for use. Note that the DLP-245SY-G will appear non-responsive if data sent from the host PC is not read from the FT245RL device by the SX48 microcontroller.

If changing drivers from the VCP to the DLL type (or vice versa), you must first uninstall the currently loaded drivers. This is accomplished by disconnecting the DLP-245SY-G adapter from the host computer and then using Add-Remove-Programs from Control Panel.

TOKEN I/O

The SX48 microcontroller on the DLP-245SY-G is shipped from the factory preprogrammed with firmware that provides rudimentary access to the port pins via either the VCP or DLL drivers. Features include the ability to read and write individual port pins as well as 8-bit port reads and writes.

The firmware in the DLP-245SY-G also provides access to the on-board EEPROM memory, and communications with digital temperature-sensing devices.

Commands sent to the Token I/O firmware must adhere to a specific communications protocol. Each command sequence contains the following information:

Byte 0:	Number of bytes in command sequence
Byte 1:	Command
Byte 2n-1:	Parameter/Data bytes
Byte n:	Checksum

The checksum is computed by exclusive-OR-ing every byte in the string. If the same checksum is calculated by the SX48 upon receipt of the packet, then a single-byte reply of 0x55 is returned to the host. In the event of a checksum error, the SX48 will return an error code of 0xAA. For example, setting port PIN_B1 high would require the following string of bytes:

0x03, 0xA6, 0xB1, 0x01, 0x15

Definition of the Bytes:

- 0x03 Number of bytes in command (checksum excluded)
- 0xA6 Command for set port pin high/low

0xB1 – Affected port pin

- 0x01 Desired state of port pin
- 0x15 Checksum of previous 4 bytes

The port pins equate to hexadecimal numeric constants as defined here:

PORT B:

PIN_B0 0xB0, PIN_B1 0xB1, PIN_B2 0xB2, PIN_B3 0xB3,

PORT C:

PIN_C0 0xC0, PIN_C1 0xC1, PIN_C2 0xC2, PIN_C3 0xC3, PIN_C4 0xC4, PIN_C5 0xC5, PIN_C6 0xC6, PIN_C7 0xC7,

PORT D:

PIN_D0 0xD0, PIN_D1 0xD1, PIN_D2 0xD2, PIN_D3 0xD3, PIN_D4 0xD4, PIN_D5 0xD5, PIN_D6 0xD6, PIN_D7 0xD7

PORT E:

PIN_E0 0XE0, PIN_E1 0XE1, PIN_E2 0XE2, PIN_E3 0xE3, PIN_E4 0xE4, PIN_E5 0xE5, PIN_E6 0xE6, PIN_E7 0xE7

The source code for the Token I/O firmware (developed for the SnXC C compiler from Grich RC) is available as a free download upon purchase of the DLP-245SY-G. Example Visual C++ source code (for Windows 98/2000/XP) for communicating with the DLP-245SY-G via the Token I/O firmware is also available for download upon purchase. The windows source code also contains the port pin definitions listed above.

TOKEN I/O COMMAND SET

0xA5 – Line In – Reads the state of a single port pin

Parameters:	Port – Select from available port pins (PIN_A3, PIN_B0, etc)	
Returns:	1 Byte: State of the port pin (0 or 1)	
Function:	This function will read the state of a single port pin. If the data direction for the	
	pin selected was set to output, the direction is first set to input.	
Example:	0x2, 0xA5, 0xA3, 0x3 - Reads the current state of port pin PIN_A3.	

0xA6 – Line Out - Sets a single port pin high or low

Parameters:	Port – Select from available port pins (PIN_A3, PIN_B3, etc)
	State – 0 or 1
Returns:	Undefined
Function:	This function will change the output state of a single port pin. If the data direction
	for the pin selected was set to input, the direction is first set to output.
Example:	0x3, 0xA6, 0xA3, 0x1, 0x7 – Sets port pin PIN_A3 high.

0xA7 – Return Board ID

Parameters:	None
Returns:	5 bytes: "245SY"
Function:	This function will return the ID of the 245xx board currently opened.
Example:	0x1, 0xA7, A6 – Reads the board ID.

0xAA – EEPROM Read

Parameters:	Address – Selects the zero-based address of the location in the EEPROM for	
	reading.	
Returns:	1 Byte: The byte of data read from the EEPROM.	
Function:	This function will read the selected location in the EEPROM.	
Example:	0x2, 0xAA, 0x2, 0xAA – Reads EEPROM Address 2, and returns a single byte of	
	data.	

0xAB – EEPROM Write

Parameters:	Address – Selects the zero-based address of the location in the EEPROM for
	writing.
	Data – Data to be written to the EEPROM.
Returns:	Undefined.
Function:	This function will write the selected location in the EEPROM.
Example:	0x3, 0xAA, 0x2, 0xFE, 0x55 – Writes a value of 0xFE to EEPROM Address 2.

0xAC – DS18S20 Start Convert

Parameters:	Port Pin – Selects the microc	controller port pin on the SX48 to be used for
	communication with the DS1	8S20 temperature sensor.
Returns:	1 Byte: A single byte indication	ng the result of trying to reset the temperature
	sensor.	
	Sensor status definitions:	99: Sensor ready
		8: Short circuit detected
		2: No sensor detected
Function:	This function will select a por	t pin for communicating with a DS18S20
	temperature sensor and star	t a temperature conversion. In addition to power and
	ground connections, a 1.5K t	o 4.7K pull-up resistor must be connected between
	VCC and the data pin of the	DS18S20 for proper communication. The
	conversion time for the DS18	3S20 is specified for a maximum of 750 milliseconds.
Example:	0x2, 0xAC, 0xB0, 0x1E – Sta	arts a temperature conversion on SX48 port pin B0.

0xAD – DS18S20 Read Data

Parameters:	Port Pin – Selects the microcontroller port pin on the SX48 to be used for
	communication with the DS18S20 temperature sensor.
Returns:	9 Bytes: The contents of the scratchpad memory in the DS18S20.
Function:	This function will select a port pin for communicating with a DS18S20
	temperature sensor and request the current contents of the DS18S20's
	scratchpad memory. A conversion (command 0xAC) must have been previously
	requested for the data to be current. Additionally, host software must wait at

least 750 milliseconds for the conversion to complete before reading the 9 bytes of data. In addition to power and ground, a 1.5K to 4.7K pull-up resistor must be connected between VCC and the data pin of the DS18S20 for proper communications. (For an example of how to calculate .1°C resolution temperature data from the 9 bytes of return data, refer to the example Windows source code.)

Example: 0x2, 0xAD, 0xB0, 0x1F – Requests 9 byte temperature data from SX48 port pin B0.

0xAE – Reserved

0xAF – Loopback

Parameters:	Data byte – The byte of data to be looped back to the host.
Returns:	1 Byte: The data byte written.
Function:	This function will echo the specified byte of data back to the host. The port pins are not affected.
Example:	0x2, 0xAF, 0x12, 0xBF – Requests the data byte 0x12 to be echoed back to the host.

0x55 – Port A Read

0x59 – Port C Read

0x5B – Port D Read

Parameters:	None
Returns:	1 Byte: The 8-bit data read from the selected port.
Function:	This function will read the specified 8-bit port and return the results to the host.
	The port is automatically configured as an input port.
Example:	0x1, 0x5B, 0x5A – Requests a read from the 8-bit data bus Port D.

0x56 – Port A Write 0x5A – Port C Write 0x5C – Port D Write

Parameters:Data byte – The byte of data to be written to the 8-bit port.Returns:UndefinedFunction:This function will write the specified data byte to the 8-pit port. Data is latched on
the port pins until changed by another command. The port is automatically
configured as an output port.Example:0x2, 0x5C, 0x12, 0xBF – Writes the data byte 0x12 to the 8-bit data bus Port D.

TABLE 1: DLP-245SY-G PINOUT DESCRIPTION



Pin #	Description
1	C0 (I/O) Port Pin C0 connected to the SX48 microcontroller
2	C1 (I/O) Port Pin C1 connected to the SX48 microcontroller
3	C2 (I/O) Port Pin C2 connected to the SX48 microcontroller.
4	C3 (I/O) Port Pin C3 connected to the SX48 microcontroller.
5	C4 (I/O) Port Pin C4 connected to the SX48 microcontroller.
6	C5 (I/O) Port Pin C5 connected to the SX48 microcontroller.

7	C6 (I/O) Port Pin C6 connected to the SX48 microcontroller.
8	C7 (I/O) Port Pin C7 connected to the SX48 microcontroller.
9	MCLR* (In) Can be used by an external device to reset the SX48. Can be left disconnected if not
	used.
10	RTCC (In) Input to the SX48's Real-Time Clock/Counter
11	RESET# (In) Can be used by an external device to reset the FT245RL. Can be left disconnected if
	not used.
12	GROUND Note: This pin was RESETO# in the original DLP-245SY
13	GROUND
14	3V3OUT (Out) Output from the integrated L.D.O. regulator. Its primary purpose is to provide the
	internal 3.3v supply to the USB transceiver cell and the RSTOUT# pin. A small amount of current
	(<=5mA) can be drawn from this pin to power external 3.3v logic if required.
15	GROUND
16	SWVCC (Out) Power from EXTVCC (Pin 19) controlled via Pin 10 (POWERN#) of the FT245RL
	and Q1 MOSFET power switch. R5 and C3 control the power-up rate to help limit inrush current.
17	GROUND
18	VCC-IO (In) 3.0 volt to +5.25 volt VCC to the FT245RL's interface pins 10-12, 14-16, and 18-25.
	When interfacing with 3.3v external logic, connect VCC-IO to the 3.3v supply of the external logic;
	otherwise, connect to the VCC to drive out at 5v CMOS level. This pin must be connected to VCC
	from the target electronics or EXTVCC.
19	EXTVCC (In) Use for applying main power (4.4 to 5.25 volts) to the module. Connect to
	PORTVCC if the module is to be powered by the USB port (typical configuration).
20	PORTVCC (Out) Power from USB port. Connect to EXTVCC if module is to be powered by the
	USB port (typical configuration). 500mA is the maximum current available to the DLP-245SY-G
	and target electronics if the USB device is configured for high power.
21	DB7 (I/O) Line 7 of the data bus between the SX48 and the FT245RL USB-FIFO.
22	DB6 (I/O) Line 6 of the data bus between the SX48 and the FT245RL USB-FIFO.
23	DB5 (I/O) Line 5 of the data bus between the SX48 and the FT245RL USB-FIFO.
24	DB4 (I/O) Line 4 of the data bus between the SX48 and the FT245RL USB-FIFO.
25	DB3 (I/O) Line 3 of the data bus between the SX48 and the FT245RL USB-FIFO.
26	DB2 (I/O) Line 2 of the data bus between the SX48 and the FT245RL USB-FIFO.
27	DB1 (I/O) Line 1 of the data bus between the SX48 and the FT245RL USB-FIFO.
28	DB0 (I/O) Line 0 of the data bus between the SX48 and the FT245RL USB-FIFO.
29	E0 (I/O) Port Pin E0 connected to the SX48 microcontroller.
30	E1 (I/O) Port Pin E1 connected to the SX48 microcontroller.
31	E2 (I/O) Port Pin E2 connected to the SX48 microcontroller.

32	E3 (I/O) Port Pin E3 connected to the SX48 microcontroller.
33	E4 (I/O) Port Pin E4 connected to the SX48 microcontroller.
34	E5 (I/O) Port Pin E5 connected to the SX48 microcontroller.
35	E6 (I/O) Port Pin E6 connected to the SX48 microcontroller.
36	E7 (I/O) Port Pin E7 connected to the SX48 microcontroller.
37	B3 (I/O) Port Pin B3 connected to the SX48 microcontroller.
38	B2 (I/O) Port Pin B2 connected to the SX48 microcontroller.
39	B1 (I/O) Port Pin B1 connected to the SX48 microcontroller.
40	B0 (I/O) Port Pin B0 connected to the SX48 microcontroller.

MECHANICAL DIMENSIONS IN INCHES (MM) (PRELIMINARY)



DISCLAIMER

Neither the whole nor any part of the information contained within or the product described in this datasheet may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder.

This product and its documentation are supplied on an as-is basis, and no warranty as to their suitability for any particular purpose is either made or implied. DLP Design will not accept any claim for damages whatsoever arising as a result of use or failure of this product. Your statutory rights are not affected.

This product or any variant of it is not intended for use in any medical appliance, device, or system in which the failure of the product might reasonably be expected to result in personal injury.

This document provides preliminary information that may be subject to change without notice.

CONTACT INFORMATION

DLP Design 1605 Roma Lane Allen, TX 75013 Phone: 469-964-8027 Fax: 415-901-4859 Email: support@dlpdesign.com Internet: <u>http://www.dlpdesign.com</u>

